






























RICHTWERTTABELLE

GAH ALBERTS



																				
Mit CE-Kennzeichnung	CE	CE	CE	CE	CE	CE	CE	CE	-	-	-	-	-	-	-	-	-	-	-	CE
max. Höhe: 120 cm  max. 250 cm		●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
max. Höhe: 150 cm  max. 250 cm	●	●	●	●		●			●	●	●	●	●	●	●	●	●	●	●	●
max. Höhe: 120 cm  max. 180 cm	●	●	●						●	●	●		●	●	●	●	●	●	●	●
max. Höhe: 150 cm  max. 180 cm	●	●	●						●	●	●		●	●	●	●	●	●	●	●
max. Höhe: 180 cm  max. 180 cm	●																			●
max. Höhe: 180 cm  max. 250 cm	●	●	●						●	●	●		●	●	●	●	●	●	●	●
max. Höhe: 200 cm  max. 250 cm	●																			
max. Höhe: 260 cm  max. 250 cm	●																			
max. Höhe: 260 cm  max. 250 cm	●																			

RICHTWERTTABELLE

Beim Bauen von Holzkonstruktionen spielt die Statik eine wichtige Rolle. Sie wird beeinflusst durch Holzstärken und -arten, Schrauben, Pfostenabstände und Bauweise. Für Ihre Sicherheit haben die gekennzeichneten Pfostenträger eine CE-Zulassung. Bei Einzel- und Doppeltoren empfehlen wir die Verwendung von H-Pfostenträgern.

www.gah.de